

## INSTRUCTION FOR BASE SUPPLIED WITH METAL FLASHING

Clean the shower area thoroughly and ensure it's free of any debris or dust.

Attach the flashing supplied with the shower base to the edges of the base, as per manufacturer's instructions.

Apply a bead of silicone sealant between the flashing and the base.

Use screws to attach the flashing to the base, as per the manufacturer's instructions.

Check that the shower base fits perfectly into the space provided.

Attach the waste to the shower base as per the manufacturer's instructions.

Apply a generous amount of silicone sealant around the perimeter of the shower base, making sure it covers the entire base.

Carefully lower the shower base into position, ensuring that it is level and aligned with the waste outlet.

Connect the waste to the plumbing as per the manufacturer's instructions.

Apply even pressure around the edges of the base to help it adhere to the floor.

Wipe off any excess silicone sealant and leave the base to dry for at least 24 hours.

Test the shower base for leaks by running water into it for a few minutes.

